

-----NOTICE-----

Installation of lamps is required before operating your new Solar Comfort

Lamp installation instructions:

#1 size Phillips head screwdriver required.

KD-8000 Solar Comfort Chassis

1. Remove the lid by unscrewing the four (4) screws located near the corners of the lid.
2. Remove the heat exchanger by removing the four screws referenced in the diagram below with an "O". **DO NOT REMOVE THE SCREWS REFERENCED WITH "X"**. Hint: When removing the heat exchanger, first lift up the end closest to the thermostat. When reinstalling, insert the end closest to the front first.
3. The lamps will be found inside the box. Install all four lamps, and then prior to reassembling, test the lamps by plugging in the unit and turning it on. **NEVER LOOK DIRECTLY INTO THE LIGHT.**

